

How to connect the Orbit Reader to NVDA

The Orbit Reader is compatible with NVDA screen reader (version 2017.1 or later) installed on your computer. You must connect it via USB (Bluetooth connection is also possible), then configure NVDA to use the Orbit Reader.

To connect the Orbit Reader to the computer, follow these steps.

1. Switch on the Orbit Reader, then connect to your computer via USB cable,
2. Press Space + Dots 2 7 to activate Remote HID mode.

To configure NVDA to use the Orbit Reader as a braille display device, do the following.

1. Press NVDA + N to open the NVDA menu, then select Preferences, Settings,
2. In the General dialog box, use Down Arrow to Braille category, then Tab to Change button and activate with Spacebar,
3. In the Braille Display combo box, press Home to locate Baum/HumanWare/APH/Orbit braille displays, then press Enter to confirm,
4. Press Escape to close the General dialog box.

When you use the Orbit Reader as a braille display, the screen reader provides translation and other braille settings.